

MINC-2

Technical Documentation ICI (Incremental Counter Interface) Submodule

Please keep for further use !

Edition date/Rev. date: 17.12.1998
Document no./Rev. no.: TRS - V - BA - GB - 0035 - 00
Software version: 1.0
File name: TRS-V-BA-GB-0035.DOC
Author: SMK

TRSystemtechnik GmbH
Eglishalde 6
D-78647 Trossingen
Germany
Tel. +49 - (0) 7425 / 228-0
Fax +49 - (0) 7425 / 228-34

Imprint

TRSystemtechnik GmbH

D-78647 Trossingen
Eglisshalde 6
Tel.: (+49) 07425/228-0
Fax: (+49) 07425/228-34

© Copyright 1998 TRSystemtechnik

Guarantee

In our ongoing efforts to improve our products, TRSystemtechnik reserve the right to alter the information contained in this document without prior notice.

Printing

This manual was edited using text formatting software on a DOS personal computer. The text was printed in *Arial*.

Fonts

Italics and **bold** type are used for the title of a document or to emphasize text passages.

Passages written in *Courier* show text which is visible on the display as well as software menu selections.

"< >" refers to keys on your computer keyboard (e.g. <RETURN>).

Note

Text following the "NOTE" symbol describes important features of the respective product.

Copyright Information ©

MS-DOS is a registered trademark of Microsoft Corporation.

Revision History

i

Note:

The cover of this document shows the current revision status and the corresponding date. Since each individual page has its own revision status and date in the footer, there may be different revision statuses within the document.

Document created:

17.12.1998

Revision	Date

Table of contents

1 General 5

2 Technical data of MINC-2 6

3 Signal description and example of MINC-2 connection 6

4 Message traffic to the FOX-20 when reading the incremental 7
channels 7

 4.1 Message structure for FOX-20 7

 4.2 Messages for MINC-2 in FOX-20..... 7

 4.3 Examples of FOX-20 messages: 8

MINC-2



Eglshalde 6, 78647 Trossingen,
Germany Tel. +497425-228-0, Fax +497425-228-34

MINC 2 ISI Submodule (Incremental Counter Interface)

24-Bit Resolution

1 General

The MINC-2 input module is a submodule, which is galvanically decoupled by means of optocouplers, for the FOX-20 basic module. The submodule provides two incremental counters.

For operation in the II/O system, you can install up to four MINC-2s in the four slots of a FOX-20 basic module. This makes possible a maximum of 8 incremental inputs per FOX-20. In addition, you can combine MINC-2s with different modules, e.g. digital outputs.




Figure: Two-Channel INC-2 Module

2 Technical data of MINC-2

Inputs	Two incremental counter inputs Reference cams galvanically decoupled
Input Level	Input voltage RS-422
Resolution	24-bit counter (twos complement)
Encoder Feed	+5 V DC
Current Consumption	0.1 A (without encoder)
Housing	Module with front panel is mounted in the FOX-10 using two screws.
Dimensions (W x H x D)	58 x 72 x 50 mm, Weight 100 g
Temperature	Operation: $\pm 0..+55^{\circ}$ C, Storage: $-20..+70^{\circ}$ C

3 Signal description and example of MINC-2 connection

Pin	Signal	I/O	Description of Channel 1
L-1	/NP		Inv. zero pulse
L-2	NP		Zero pulse
L-3	RN-		Inv. reference cam
L-4	RN+		Reference cam
L-5	/B		Inv. channel B
L-6	B		Channel B
L-7	/A		Inv. channel A
L-8	A		Channel A
L-9	+5V	Supply	Supply voltage for the encoder
L-10	0 V	Ground	
Pin	Signal	I/O	Description of Channel 2
R-1	/NP		Inv. zero pulse
R-2	NP		Zero pulse
R-3	RN-		Inv. reference cam
R-4	RN+		Reference cam
R-5	/B		Inv. channel B
R-6	B		Channel B
R-7	/A		Inv. channel A
R-8	A		Channel A
R-9	+24V	Supply	Supply voltage for the encoder
R-10	0 V	Ground	

Pin designations: L: left-hand row
R: right-hand row

4 Message traffic to the FOX-20 when reading the incremental channels

4.1 Message structure for FOX-20

FOX-20 allows you to use all the possible digital and analog submodules, as well as incremental counter modules, for example. In this case, there are only 16 bits of user data in the FOX-20 message. Data byte DB0 is for addressing the slot and the word no./channel no. within a slot; data byte DB1 is for future expansion and currently always contains the value 80 hex. The 16 bits of user data are transferred in data bytes DB2 and DB3.

If the MINC-2 needs only 16 bits of encoder data, this can be carried out using one message.

16-bit resolution:

Every access of the counter is carried out by one (1) message.

If, on the other hand, all 24 bits of the counter are used, two additional messages are needed. The first message interrupts the update of the counter. It is now possible to completely read out one counter with two subsequent messages. The last message reenables the updates for the module.

The system carries out accessing of the counter by means of two (2) messages to disable the update and to enable the updates as well as two (2) messages per counter to load the encoder position.

The FOX code (30 hex) is used as the control byte in the FOX-20 (30 hex means FOX-20 message).

The FOX-20-internal slot/Word/channel address is specified in data byte DB0 of the message.

DB0 is divided into two:

The top nibble contains the number of the submodule. The first submodule that is plugged in to the left-hand slot of the FOX-20 basic module is given submodule number 1.

From right to left, the possible numbers read 1, 2, 3 and 4.

The bottom nibble defines the channel of the submodule. Example: incremental counter channel 1 is given channel number 1, incremental counter channel 2 is given channel number 2. The top nibble defines the word address of the slot. Incremental counter 1 occupies word 1 and word 2, incremental counter 2 occupies word 3 and word 4.

The actual user information is in DB2 and DB3.

At 16-bit resolution, DB2 contains the low byte and DB3 the high one.

At 24-bit resolution, DB2 contains the first message and the low byte, DB3 contains the middle byte; in the second message, DB2 contains the high byte.

At 25-bit resolution, DB3 of the second message contains bit 2^{24} .

4.2 Messages for MINC-2 in FOX-20

ADR	= Module address	= 1 .. 254 dec
ContrlByte	= Read/Write FOX-20	= 30 hex
DB0	= ChannelSelect	= HighNibble := SubmoduleSlot 1..4 LowNibble := WordNumber 1,2,3,4,5,6,7,8 and 15
DB1	= Must be 80 hex	
DB2	= LSB data	
DB3	= MSB data	

4.3 Examples of FOX-20 messages:

Example 1:

Two MINC-2 submodules with two channels each are plugged in the FOX-20. All four (4) counter values are to be read out. The counters supply 24- (25-) bit resolution.

The first message tells the FOX-20 basic module that the counters are to be latched on all 24 bits, and that it is not to carry out any more updates until enabling. Stopping updating is achieved by writing a 1 in DB 2 on slot no. 0, word address 15:

Address	ControlByte	DB	0	DB 1	DB 2	DB 3
Address	ControlByte	Slot	Word	Fixed 80 hex	Low Byte	High Byte
e.g. 1 (Box 1)	0011 0000	0000	1111	1000 0000	0000 0001	xxxx xxxx

The second message reads in the least-significant word of the first counter (slot 1, word/channel 1):

Address	ControlByte	DB	0	DB 1	DB 2	DB 3
Address	ControlByte	Slot	Word	Fixed 80 hex	Low Byte	High Byte
e.g. 1 (Box 1)	0011 0000	0001	0001	1000 0000	0011 1100	0100 0000

The third message reads in the most-significant word of the first counter (slot 1, word/channel 2):

Address	ControlByte	DB	0	DB 1	DB 2	DB 3
Address	ControlByte	Slot	Word	Fixed 80 hex	Low Byte	High Byte
e.g. 1 (Box 1)	0011 0000	0001	0010	1000 0000	0000 0001	0111 1111

The fourth message reads in the least-significant word of the second counter (slot 1, word/channel 3):

Address	ControlByte	DB	0	DB 1	DB 2	DB 3
Address	ControlByte	Slot	Word	Fixed 80 hex	Low Byte	High Byte
e.g. 1 (Box 1)	0011 0000	0001	0011	1000 0000	0101 1010	1111 0011

The fifth message reads in the most-significant word of the second counter (slot 1, word/channel 4):

Address	ControlByte	DB	0	DB 1	DB 2	DB 3
Address	ControlByte	Slot	Word	Fixed 80 hex	Low Byte	High Byte
e.g. 1 (Box 1)	0011 0000	0001	0100	1000 0000	0000 0000	0000 1111

The sixth message reenables the module the system updates the counters again.
Write a 0 in DB 2 on slot 0, word/channel 15

Address	ControlByte	DB	0	DB 1	DB 2	DB 3
Address	ControlByte	Slot	Word	Fixed 80 hex	Low Byte	High Byte
e.g. 1 (Box 1)	0011 0000	0000	1111	1000 0000	0000 0000	xxxx xxxx

The read-out counter value of encoder 1 is:

(Bit 25 Bit 0) 1 0111 1111 0011 1100 0100 000

The read-out counter value of encoder 2 is:

(Bit 25 Bit 0) 0 0000 1111 0101 1010 1111 0011

Example 2:

One MINC-2 submodule with two channels is plugged in the FOX-20. One counter value is to be read out. The sixteen-bit resolution is adequate, since a linear absolute encoder, for example, is used.

Access to slot 1/counter 1, 16-bit resolution

Encoder Position = 0100 0000 0011 1100

Address	ControlByte	DB	0	DB 1	DB 2	DB 3
Address	ControlByte	Slot	Word	Fixed 80 hex	Low Byte	High Byte
e.g. 1 (Box 1)	0011 0000	0001	0001	1000 0000	0011 1100	0100 0000